

MP-Test

This MP tester is suitable for testing the interfaces on HR systems and LRM systems. It can be used in connection with a multimeter.



Picture may vary.

Technical Data

Article no.

827 094 001
